

INSTRUCTIONS: Installation of the ChumpCar number background panel, sponsor panel, and night racing panel illumination light



The number background panel is to be located as centered as possible on BOTH the driver's and passenger's door. Number panels can ONLY be placed on the doors– no other location. The panel should be positioned as high on the door as possible to provide the largest "flat space" for the number. The Sponsor Panel should be mounted ahead of the number panel, around the area under the side mirror. Avoid having the panels roll under the door towards design lines, body creases and/or the sill.

If you plan on racing at any event that requires headlights, number panel illumination is required. The bottom of the light is required to lineup with the upper, black border outline of the panel and the light must be centered on the panel's length. (See red box, above, for example.) Three holes must be drilled for hardware attachment and wiring. For the easiest wiring, splice the light power wire into a taillight or headlight wire.

The third number panel is to be located on the roof of the car (with numbers pointed toward the passenger side of the vehicle) or, for convertibles and open cars, on the hood (again, with numbers pointed to the passenger side of the vehicle). The panel can be angled (no more than 30degrees).

